



RV STEP OPERATION



1. Firmly grasp Grab Bar.
2. Pull Grab Bar outward and down until top step is fully exposed and cannot be pulled out any farther.



3. Grasp 2nd Grab Bar from the top of the 2nd step.
4. Pull Grab Bar outward and down until bottom step is fully exposed and cannot be pulled out any farther.

***RV Step Service/Warranty information can be obtained
by calling 866-524-7821 or going online at www.lci1.com.***